

Installing Crystals on Large Chandelier: ONLY INSTALL CRYSTALS AFTER CHANDELIER is COMPLETELY PUT TOGETHER.

Step 1

Put cotter pins onto 4 of the 3 crystal strands



Step 2

Place a cotter pin through 1 of 4 holes on a clear dish and secure by spreading the cotter pin to prevent it from falling off. Note: You may have previously installed crystal dishes in step 12 of Chandelier assembly. If so you can leave it attached or remove it for crystal installation.



Step 3

Add a 3 crystal strand to each chandelier arm as seen here. (Arms attached)



Step 4

Add a 6 crystal strand and the 12 crystal strand to the same place on each chandelier arm. When the chandelier is complete you will attach each of the 12 crystal strands to the arm next to it connecting all arms together. (Arms attached)



Step 5

Place a clear plastic crystal dish with crystals now installed onto the light outlet.



Step 6 Place a gold sleeve over the outlet to hold the dish on. Lastly screw light into the power receptacle.



Your 8 Arm Crystal Chandelier is Now Complete